



PROCESSES:

1. CHIP OUT CONCRETE 1/2" - 1" DEPTH AND CURTAIL 4" - 6" BACK
2. FILL WITH RES-TEK RT-05 POLYMER CONCRETE TO WITHIN 1/8" OF TOP OF EXISTING DRAIN
3. FINISH WITH RES-TEK ACRYLIC FLOORING FLUSH TO DRAIN TOP