



PROCESSES:

1. CHIP OUT CONCRETE 1/2" - 1" DEPTH AND CURTAIL 4" - 6" BACK
2. FILL WITH RES-TEK PUR-GUARD HD-T TO WITHIN 3/16" - 3/8" OF TOP OF EXISTING DRAIN
3. FINISH WITH RES-TEK PUR-GUARD FLOORING FLUSH TO DRAIN TOP